



Quick Installation Guide 300N Wireless Cardbus Adapter

Model # AWLC6080



Package Contents:

- Wireless Cardbus Adapter
- Driver & Utility CD
- Quick Installation Guide

FIG. 1.2



Step 3 The Autorun screen will pop up. Select **Install Utility and Driver** from the menu.

Section 1

Install Utility Software

This Quick Installation Guide only provides basic instructions. For more advanced features such as configuring encryption settings, please refer to the User's Manual on the provided CD.

Note: Be sure to power off your computer before inserting the Cardbus adapter.


Step 1 Insert the Cardbus adapter into an available Cardbus slot and turn on your computer.

Step 2 After turning on the computer, Windows will launch the **Found New Hardware Wizard**. The Found New Hardware Wizard appears differently depending on your operating system. Click **Cancel** to quit the wizard and insert the Installation CD into your CD drive.




Note: If the Autorun screen doesn't appear automatically go to **Start, Run,** and type **D:\Utility\Setup.exe** (where **D** is the letter of your CD drive,) and click **OK**.


Windows Vista users: At this point, you may get a warning message like the one below. Make sure that you click **Allow** to continue with the installation.




Step 4 Click **Next** at the welcome screen.



Step 5 Click **Next** to accept the default destination folder.




Step 6 Click **Continue Anyway** at the Windows Logo Screen. (For Windows 2000, click **Yes** at the Digital Signature Not Found prompt).




For Windows Vista, click the **Install this driver software anyway** button when the security warning appears.




Step 7 Click **Yes, I want to restart my computer now** and then **Finish** to restart your computer.




Step 8 After the computer is restarted, Windows will ask to connect to Windows Update, select **No, not this time** and click **Next**. If this screen does not appear, you can skip to Section 2.




Step 9 Select **Install the software automatically** and click **Next**.



Step 10 Click **Continue Anyway** at the Windows Logo Screen. (For Windows 2000, click **Yes** at the Digital Signature Not Found prompt).



For Windows Vista, click the **Install this driver software anyway** button when the security warning appears.



Step 11 Click **Finish**.



Section 2

Configuring the Wireless Adapter

Note to Windows XP Users:

You must disable the Wireless Zero Configuration Utility. Please follow the steps below to disable XP's wireless utility. Windows Vista users can skip the following instructions and go to **Step 1**.

Double-click on the **Wireless Network Connection** icon in the system tray and then click on **Properties** or **Advanced**.




When the new wireless network connection properties window appears, go to the **Wireless Networks** tab, uncheck the **Use Windows to configure my wireless network settings** check box and click **OK**.



Step 1 To open the utility, double click on the Wireless Monitor icon in the system tray at the bottom right-hand corner of your screen.



Step 2 Go to the **AP List** tab, select the **SSID** (Network Name) of the wireless network you wish to connect to, and click **Connect**.



If the network you are attempting to connect to is configured for encryption, you will see an orange lock icon next to the network.



